

Quick-Start Guide

SMARTHOME MANAGER ESSENTIAL, TIMER USB

FOR MODELS: #2814U, 2814UB

Your Timer System includes:

- 1 USB Computer Interface/PowerLinc Controller with USB cable
- Timer Software CD-Rom



Need Help? For assistance call your friendly support representative @ 800-SMARTHOME (800-762-7846)

How to install Smarthome Timer Software

- Step 1.** Two SignalLinc RF (#2442P) **must** be installed if your home does not already have them.
- Step 2.** Plug a USB cable into an available USB port on your computer or your USB hub.
- Step 3.** Plug the PowerLinc Controller into an unswitched wall receptacle in an easy to reach location.
- Step 4.** Plug the other end of your USB cable into the USB port at the bottom of the USB Computer Interface module.
- Step 5.** Insert CD-Rom into CD Rom Drive.
- Step 6.** A wizard will automatically guide you through the installation process.
- Step 7.** After completing the installation process, open the Smarthome Timer Software by double clicking on Smarthome Timer Software shortcut on your desktop.

Getting Started

- Step 1.** From the Main Menu, go to Setup and choose Set Location for Sunrise/Sunset.
- Step 2.** Select the State/City closest to your location.
- Step 3.** Select Finish to save your selection and return to the Main Menu.
- Step 4.** From the Main Menu, go to Setup and choose Devices.
- Step 5.** Choose Add a Device and follow the step-by-step instructions to add a device to be controlled by your computer or by a timer application.
- Step 6.** Once you have successfully enrolled a device/s, return to Setup and choose Timers.
- Step 7.** Choose Add a Timer and follow the instructions to create a timer using the enrolled devices.

Congratulations! You can now control your devices through your computer or on a timer.

Notes

- Each time the Smarthome Timer Software is opened, the application time will sync with your computer's time. If you change the time of your computer while software is running, close and open the application again.
- Your computer does not need to be on in order for timers to work, but you will need to turn on your computer and open the software if you wish to control devices from your computer or add, delete or edit a timer or device.
- The advanced User's Guide can be found at www.smarthome.com/2814ub.html

Smarthome Limited Warranty

Smarthome warrants to the original consumer of this product that, for a period of one year from the date of purchase, this product will be free from defects in material and workmanship and will perform in substantial conformity to the description of the product in the owner's manual. This warranty shall not apply to defects or errors caused by misuse or neglect.

rev. 121505