



INSTRUCTIONS FOR **FIRST TIME USE ONLY:**

This unit requires priming prior to first time use. **Please follow these instructions to be sure you set up your unit correctly. Fill unit over sink in case of accidental spills or overflow.**

BEFORE YOU START: Your unit will ship with a black rubber disc temporarily fastened to the nozzle. Should the disc come dislodged during transit, please place the black rubber disc securely into the dispenser as seen in the illustration (figure1).




STEP 1: Unscrew the top of the unit from the bottom of the unit by turning the top in a counter-clockwise direction. Take care not to remove the black rubber stopper from the nozzle.




STEP 2: Fill the bottom of the unit with liquid soap as indicated in the illustration.



STEP 3: Reassemble the top of the unit to the bottom of the unit by turning in a clockwise direction, again taking care to keep the rubber stopper in place.




STEP 4: Push the plunger of the syringe in, and insert the syringe directly into the black rubber disc in the soap dispenser nozzle.




STEP 5: Holding the syringe in place with your hand, slowly pull back on the syringe to draw the air out of the unit and allow the soap or lotion to flow through the unit.

NOTE: Depending on the thickness of the soap used, steps 4 and 5 may need to be repeated several times until the soap flows smoothly from the unit. Do so by removing the syringe from the unit and expelling the air by pushing the plunger in, then continue with steps 4 and 5.



STEP 6: Remove the tape from the rubber stopper. Remove the rubber stopper from the unit and discard it.



Put in the batteries and turn the unit on, your soap dispenser is now ready for use!

Please read the enclosed instruction manual for battery installation and detailed operating tips.

READ ME FIRST